

**Cres Cor Sterno Cabinet
Model #102-ST-1841-E**

OPERATING INSTRUCTIONS



DO NOT USE MORE THAN THREE (3) CANS OF FUEL AT ONE TIME. CABINET BODY MAY GET TOO HOT.

HOW TO USE THE STERNO CABINET:

1. Cabinet operates with three (3) standard size 7-oz. cans of fuel for an overall average holding temperature of 170°F (depending on location in cabinet):
 - a) Top = 156°F
 - b) Middle = 169°F
 - c) Bottom = 209°F
2. Cabinets hold hot precooked foods. It is NOT to be used as an oven.
3. Top and bottom vents (louvers) in door MUST be open for proper air flow.
4. How to hold with added humidity:
 - a) Place a 12" x 20" hotel pan, approximately half full of hot water, on an 18" x 26" sheet pan.
 - b) Slide sheet pan into cabinet, two shelf spaces above the flame
 - c) Do not block air flow at rear of cabinet.
5. Three (3) 7-oz. cans of gelatin fuel will burn for approximately two (2) hours.

Wipe up spills as soon as possible with a soft, damp cloth